

Board	Input	Description	Microphone	Rent?	Pair	Notes	Sub-Group	XLR '	Stand
Yamaha PM4000	1	Oboe 1	AKG C-391	R	B-1			25	Short, no boom
Yamaha PM4000	2	Oboe 2	AKG C-391	R	B-2			25	Short, no boom
Yamaha PM4000	3	Clarinet 1	Shure SM58	CM	B-3			25	Short, no boom
Yamaha PM4000	4	Clarinet 2	Shure SM58	CM	B-4			25	Short, no boom
Yamaha PM4000	5	Bass Clarinet	AKG C-391	R	B-5			25	Short, no boom
Yamaha PM4000	6	Bass Clarinet	AKG C-391	R	B-6			25	Tall, short boom
Yamaha PM4000	7	Bassoon	AKG C-391	R	B-7			25	Tall, short boom
Yamaha PM4000	8	Flute 1	Shure MX-418	R	B-8			25	Tall, short boom
Yamaha PM4000	9	Flute 2	Shure MX-418	R	B-9			25	Tall, short boom
Yamaha PM4000	10	Harp	ECM-44B	R	B-10			50	
Yamaha PM4000	11	Majesty	Senn. Wrls	MD				50	
Yamaha PM4000	12	Majesty	Senn. Wrls	MD					
Yamaha PM4000	13	Majesty	Senn. Wrls	MD					
Yamaha PM4000	14	Majesty	Senn. Wrls	MD					
Yamaha PM4000	15	Majesty	Senn. Wrls	MD					
Yamaha PM4000	16	Majesty	Senn. Wrls	MD					
Yamaha PM4000	17	Majesty	Senn. Wrls	MD					
Yamaha PM4000	18	Majesty	Senn. Wrls	MD					
Yamaha PM4000	19	Majesty	Senn. Wrls	MD					
Yamaha PM4000	20	Piano Scene	AT 853	MD	D-10				
Yamaha PM4000	21	Piano Scene	AT 853	MD	D-11				
Yamaha PM4000	22	Scene Grand PNO1	AKG C3000	MD	D-12			25	tall, boom
Yamaha PM4000	23							25	tall, boom
Yamaha PM4000	24	Orchestra PNO	AKG C3000	R	B-11			50	tall, boom
Yamaha PM4000	ST1	Brass and Perc Sub-	from A&H GL2400		Grps 1,2				
Yamaha PM4000	ST2	String Sub-Mix	from A&H GL2400		Grps L,R				
Yamaha PM4000	ST3	Drum and Ryth Sub-	from A&H GL2400		Grps 3,4				
Yamaha PM4000	ST4	CD Player (iPod?)							
Yamaha PM4000	25	Plew Wrls	Senn.	CM					
Yamaha PM4000	26	Wom. Chamber 1	AT 853	R	C-1				
Yamaha PM4000	27	Wom. Chamber 2	AT 853	R	C-2				
Yamaha PM4000	28	Scene 2a	AT 853	R	C-3			100	
Yamaha PM4000	29	Scene 3	AT 853	R	C-4			100	
Yamaha PM4000	30	Scene 4	AT 853	R	D-1			100	
Yamaha PM4000	31	Scene 5a	AT 853	R	D-2			100	
Yamaha PM4000	32	Scene 5b	AT 853	R	D-3			100	
Yamaha PM4000	33	Scene 6	AT 853	R	D-4			100	
Yamaha PM4000	34							100	
Yamaha PM4000	35	WW Ensemble	Nuemann KM184	R	D-5			50	Tall Boom
Yamaha PM4000	36	WW Ensemble	Nuemann KM184	R	D-6			50	Tall Boom
Yamaha PM4000	37	Bells 1	AT 853	R	C-5			25	tall

Yamaha PM4000	39	Bells 3	AT 853	R	C-7			50	tall
Yamaha PM4000	40							50	tall
Yamaha PM4000	41	Organ	Senn MD421	R	B-21			50	short, short boom
Yamaha PM4000	42	SOLO Mic	AKG C-535	R	B-22			50	tall, boom
Yamaha PM4000	43	Choir 1	AT 853	R	B-23			50	
Yamaha PM4000	44	Choir 2	AT 853	R	B-24			25	
Yamaha PM4000	45	Choir 3	AT 853	R	B-25			25	
Yamaha PM4000	46	Choir 4	AT 853	R	B-26			25	
Yamaha PM4000	47	Choir 5	AT 853	R	B-27			25	
Yamaha PM4000	48	Choir 6	AT 853	R	B-28			50	

Board	Input	Description	Microphone	Rent?	Pair	Notes	Sub-Group	XLR '	Stand
A&H GL2400	1	Violin 1	Shure MX-418	R	A-1		L,R	25	tall, short boom
A&H GL2400	2	Violin 2	Shure MX-418	R	A-2		L,R	25	tall, short boom
A&H GL2400	3	Violin 3	Shure MX-418	R	A-3		L,R	25	tall, short boom
A&H GL2400	4	Violin 4	Shure MX-418	R	A-4		L,R	25	tall, short boom
A&H GL2400	5	Violin 5	Shure MX-418	R	A-5		L,R	25	tall, short boom
A&H GL2400	6	Viola 1	Shure MX-418	R	A-6		L,R	25	tall, short boom
A&H GL2400	7	Viola 2	Shure MX-418	R	A-7		L,R		
A&H GL2400	8	Cello 1	AKG C-3000	R	A-8		L,R	25	short, short boom
A&H GL2400	9	Cello 2	AKG C-3000	R	A-9		L,R	25	short, short boom
A&H GL2400	10	String Bass	AKG C-3000	R	A-10		L,R	50	short, short boom
A&H GL2400	11								
A&H GL2400	12	Tympani	AKG C-391	R	A-11		1,2	25	tall, boom
A&H GL2400	13	Chimes	AKG C-391	R	A-12		1,2	25	tall, boom
A&H GL2400	14								
A&H GL2400	ST1 (15)								
A&H GL2400	ST2 (16)								
A&H GL2400	17	Kick	Shure PG52	CM	A-16		3,4	25	
A&H GL2400	18	Snare	Shure SM57	CM	A-17		3,4	25	
A&H GL2400	19	Drum Ovhd L	Shure PG81	CM	A-18		3,4	25	
A&H GL2400	20	Drum Ovhd R	Shure PG81	CM	A-19		3,4	25	
A&H GL2400	21	Elec. Bass?	Direct	CM	A-20		3,4	50	
A&H GL2400	22	Acou. Guitar?	AKG 414	MD	??		3,4		short, short boom
A&H GL2400	23								
A&H GL2400	24	French Horn 1	Senn MD421	R	A-21		1,2	25	short, no boom
A&H GL2400	25	French Horn 2	Senn MD421	R	A-22		1,2	50	short, no boom
A&H GL2400	26	Trombone 1	SM57	R	A-23		1,2	25	short, no boom
A&H GL2400	27	Trombone 2	SM57	R	A-24		1,2	25	short, no boom
A&H GL2400	28	Trombone 3	SM57	R	A-25		1,2	50	short, no boom
A&H GL2400	29	Trumpet 1	SM57	R	A-26		1,2	25	short, no boom
A&H GL2400	30	Trumpet 2	SM57	R	A-27		1,2	50	short, no boom
A&H GL2400	31	Trumpet 3	SM57	R	A-28		1,2	50	short, no boom
A&H GL2400	32	Tuba	SM57	R	??		1,2	25	tall, boom

Cable Length	Number Needed	Number Extra	Total
10' jumper	15	5	20
25'	37	5	42
50'	18	5	23
100'			

Stand Type	Quantity
short, short boom	6
short, no boom	13
Tall, with boom	12
Tall, no boom	5

Description	Rent?	How many	Price per	Extended	07 Price Extended
Shure MX-418	R	10	20	1320	840
AKG C-391	R	9	15	450	405
AT 853	R	20	15	270	675
AKG C3000	R	4	20	240	240
Senn. MD421	R	3	15	135	135
AKG C535	R	1	20	60	60
SM57	R	7	10	210	210
ECM-44B	R	2	20		180
				2685	2745